

- U8379 Shock Set Instructions**
- A x12**
Shim 0.05
 - B x4**
M2 x 6 Csk Screw
 - C x4**
Red 'O' Ring

⚠ Make four shocks the same.

⚠ For better sealing add shims. 'A'
For less friction remove shims.
We suggest to start with 2 shims.

TEAM TIP

After building the shocks, o'rings 'C' will expand slightly in the oil. This creates a perfect fit. If you have time, rebuilding the shocks after at least 5 hours will result in an easier, air free build.

If you do not have time, in the first build, do not move the shock shaft until the shock top is sealed. Do not leave o'rings submerged in oil.

⚠ The factory setting has 2 shims here.

